

ODU-MAC removal tool for 0.76 - 4.0 mm contacts

REMOVAL TOOL II Removal of the still unassembled contact (without cable, which may have to be cut off). The removal tool is pressed from behind into the insulator until a quiet click is heard. The contact can be removed from the insulator by lightly pushing it with the extraction tools.



Basic information

Part number	087.611.001.001.000
Category	Tool

Further technical information and downloads

[Assembly Instruction](#)